
## **EPORT**

## **Edge Port Module Block**

## **Summary**

The EPORT has eight external interrupt pins. Each pin may be configured individually as a low level-sensitive interrupt pin, an edge-detecting interrupt pin (rising edge, falling edge, or both), or a general-purpose I/O pin.



## **Features**

- Rising/falling edge select
- ➤ Low-level sensitive
- ➤ Ability for software generation of external interrupt event
- ➤ Interrupt pins configurable as general-purpose I/O

To obtain more information about the EPORT or other  $C^*Core^{TM}$  products, please contact the  $C^*Core$  Technology Co., Ltd. by phone: 0512-68091377, email:  $\underbrace{support@china-core.com}$  or web:  $\underbrace{http://www.china-core.com}$ .  $C^*Core^{TM}$  is a trade mark of  $C^*Core$  Co., Ltd.

Tel/Fax: 0512-68091375/68096251

Email: support@china-core.com